C19A_ENG_03244A 1/20/04 11:53 AM Page 1

SAMSUNG

DVD TELEVISION

Owner's Instructions

Before operating the unit,
please read this manual thoroughly,
and retain it for future reference.

REMOTE CONTROL
ON-SCREEN MENUS
DVD / VCD / CD / MP3 PLAYER
TELETEXT FUNCTION (depending on the model)

Safety Instructions

ENG

- ***Do not expose the television to extreme temperature conditions or to extreme humidity conditions.***
- ***Do not expose the television to direct sunlight and other sources of heat.***
- ***Do not expose the television to any liquids.***
- ***Never put objects of any kind into the television, and do not place a water-containing vessel on the television.***
- ***During a storm conditions (especially when there is lightning) unplug the television from the mains socket and aerial.***
- ***Do not step on or twist the power cord.***
- ***Do not overload wall outlets or extension cords as this can result in a risk of fire or electric shock.***
- ***Please use a soft and dry cloth (not containing volatile matter) when you clean the TV.***
- ***If the television is broken, do not try to repair it yourself. Contact qualified service personnel.***
- ***If the remote control is not used for a long period of time, remove the batteries and store it in a cool, dry place.***
- ***Do not drop the remote control.***

☛ ***Displaying any stationary images that exceed the long time, it can cause uneven aging of picture tubes (CRTs) that leave subtle, but permanent burned-in ghost images in the television picture. To avoid this, vary the programming and images, and primarily display full screen moving images, not stationary patterns or dark bars.***

This device is not for use in industrial environments.

C19A_ENG_03244A 1/20/04 11:53 AM Page 3

Caution

ENG


CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO PREVENT ELECTRICAL SHOCK, DO NOT REMOVE REAR COVER, NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING: TO PREVENT DAMAGE WHICH MAY RESULT IN FIRE OR SHOCK HAZARD. DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

The lightning flash and arrow head within the triangle is a warning sign alerting you of “dangerous voltage” inside the product.



The exclamation point within the triangle is a warning sign alerting you of important instructions accompanying the product.

☛ ***The main voltage is indicated on the rear of the TV set and the frequency is 50 or 60Hz.***

C19A_ENG_03244A 1/20/04 11:53 AM Page 4

ENG

Contents (continued)

◆ **FOREWORD**
- Safety Instructions 2
- Caution 3

◆ **CONNECTING AND PREPARING YOUR TELEVISION**
- Control Panel of Your Television 6
- Connection Panel of Your Television 7
- Infrared Remote Control (Television and Teletext Functions) 8
- Infrared Remote Control (DVD Functions) 9
- Inserting the Batteries in the Remote Control 10
- Connecting to an Aerial or Cable Television Network 10
- Switching Your Television On and Off 11
- Placing Your Television in Standby Mode 11
- Automatic Degaussing to Remove Colour Patches 12
- Becoming Familiar with the Remote Control 13
- Plug and Play Feature ..... 14~15
- Choosing Your Language 15

◆ **SETTING THE CHANNELS**
- Storing Channels Automatically 16
- Storing Channels Manually ..... 17~18
- Skipping Unwanted Channels 19
- Fine Tuning Channel Reception 20
- Sorting the Stored Channels 21
- Activating the Child Lock 22
- Displaying Information 23

◆ **USING YOUR TELEVISION**
- Changing the Picture Standard 23
- Adjusting the Picture Settings 24
- Selecting the Picture Size (depending on the model) 25
- Activating/Deactivating the Digital Noise Reduction Feature 25
- Viewing Pictures From External Sources 26
- Setting the Blue Screen 26
- Changing the Sound Standard 27
- Adjusting the Sound Settings 27
- Setting the Current Date and Time 28
- Switching the Television On and Off Automatically 29
- Setting the Sleep Timer 30
- Locking the Front Panel 30

Symbols **Press** **Important** **Note**

C19A_ENG_03244A 1/20/04 11:53 AM Page 5

Contents

ENG

◆ **USING THE DVD FUNCTION**

- Playing a Disc ..... 31~34
- Using the Search and Skip Functions 35
- Using the Disc Menu 36
- Using the Title Menu 36
- Displaying the Disc Information 37
- Using the Zoom Function (DVD/VCD) 38
- Using the Bookmark Function (DVD/VCD) 39
- Repeat Play 40
- Using the EZ View (depending on the disk) 41
- Program Play (CD) 42
- Changing the Camera Angle 42
- Setting up the Language Features 43
- Setting up the Audio Options 44
- Setting up the TV Aspect 45
- Setting up the Display Options 46
- Setting up the Parental Control 47

◆ **USING THE TELETEXT FUNCTION**

- Teletext Feature 48
- Displaying the Teletext Information 49
- Selecting Display Options 50
- Selecting a Teletext Page 51
- Storing Teletext Pages 52

◆ **ADDITIONAL INFORMATION ON CONNECTIONS**

- Connecting to the External Input/Output 53
- Connecting to the Digital Audio Outputs 53
- Connecting to the Audio/Video Input 54
- Connecting Headphones 54

◆ **RECOMMENDATIONS FOR USE**

- SCART Connector Wiring 55
- Disc Type and Characteristics 56
- Technical Specifications 57
- Troubleshooting: Before Contacting Service Personnel ..... 58~59
- Wiring the Mains Power Supply Plug (UK Only) 60

Control Panel of Your Television

ENG

➢ The actual configuration on your TV may be different, depending on your model.



❶ **OPEN/CLOSE**
Press to open and close the disc tray.

❷ **STOP**
Press to stop the disc.

❸ **SKIP/SEARCH**
Press to skip or search the title, chapter or track.

❹ **PLAY/PAUSE**
Press to play or pause a video tape.

❺ **– ◢ +**
Press to increase or decrease the volume.

❻ **∨ C/P.⏻ ∧**
Press to change channels.

❼ **MENU**
Press to display the on-screen menu.

❽ **Remote Control Sensor**
Aim the remote control towards this spot on the TV.

❾ **STAND BY** (indicator)
Lit when TV power is Off.

Connection Panel of Your Television

➢ The actual configuration on your TV may be different, depending on your model.

ENG

Side of the TV



Rear of the TV



➢ For further details about connection, refer to pages 53~54.

☛ Whenever you connect an audio or video system to your television, ensure that all elements are switched off.

Refer to the documentation supplied with your equipment for detailed connection instructions and associated safety precautions.

Be sure to turn OFF the SCART device to connect to the side AV input Port.

Infrared Remote Control (Television and Teletext Functions)

ENG



➢ Operation of remote control may be affected by bright artificial light near to the TV set.

Infrared Remote Control (DVD Functions)

ENG



ENG

Inserting the Batteries in the Remote Control







You must insert or replace the batteries in the remote control when you:

- ***Purchase the television***
- ***Find that the remote control is no longer operating correctly***

1 Remove the cover on the rear of the remote control by pressing the symbol (▼) downwards and then pulling firmly to remove it.

2 Insert two R03, UM4, "AAA" 1.5V or equivalent batteries taking care to respect the polarities:
- **+** on the battery against **+** on the remote control
- **–** on the battery against **–** on the remote control

3 Replace the cover by aligning it with the base of the remote control and pressing it back into place.

Connecting to an Aerial or Cable Television Network



To view television channels correctly, a signal must be received by the set from one of the following sources:

- ***An outdoor aerial***
- ***A cable television network***
- ***A satellite network***

1 In the first three cases, connect the aerial or network input cable to the 75Ω coaxial socket on the rear of the television.

2 If you are using an indoor aerial, you may need to turn it when tuning your television until you obtain a picture that is both sharp and clear.
For further details, refer to:
- "Storing Channels Automatically" on page 16
- "Storing Channels Manually" on page 17

Switching Your Television On and Off

ENG

The mains lead is attached to the rear of your television.

☛ If you have purchased this television in the United Kingdom, refer to page 60 for further instructions on plug wiring.

Front of the TV



1 Plug the mains lead into an appropriate socket.

➢ The main voltage is indicated on the rear of the television and the frequency is 50 or 60Hz.

2 Press the " **I** " button (On/Off) on the front of the television.

Result: The Standby indicator on the front of the television lights up.



3 Press the **POWER** (⏻) button on the remote control to switch the television on.

Result: The programme that you were watching last is re-selected automatically.

➢ If you have not yet stored any channels, No clear picture appears. Refer to "Storing Channels Automatically" on page 16 or "Storing Channels Manually" on page 17.

4 To switch your television off, press again the **POWER** (⏻) button on the front of the television.

Placing Your Television in Standby Mode

Your television can be placed in Standby mode, in order to reduce the power consumption.

The Standby mode can be useful when you wish to interrupt viewing temporarily (during a meal, for example).



1 Press the **POWER** (⏻) button on the remote control.

Result: The screen is turned off and the Standby indicator on the front of the television lights up.

2 To switch the television back on, simply press again the **POWER** (⏻) button on the remote control.

☛ Do not leave your television in Standby mode for long periods of time (when you are away on holiday, for example). Turn your television off by pressing the " **I** " button (On/Off) on the front of the television. It is best to unplug the set from the mains and aerial.

Automatic Degaussing to Remove Colour Patches

ENG

A degaussing coil is mounted around the picture tube so that external degaussing after moving the receiver is normally unnecessary. If the receiver is moved or placed in a different direction, or, a coloured patch appears on the screen, the main power switch must be switched to the off position for 120minutes or the power cord must be unplugged for the same interval to allow the automatic degauss circuits to operate properly.

For safety, the receiver should be switched off from the main power switch when it is unattended.

☛ Magnetic fields can cause your television to malfunction. Degaussing is a process that neutralises magnetic fields.

Becoming Familiar with the Remote Control

ENG

The remote control is used mainly to:

- ***Change channels and adjust the volume***
- ***Set up the television using the on-screen menu system***

The following table presents the most frequently used buttons and their functions.

Button	Viewing Function	Menu Function
⌃	Used to display the next stored channel.	–
⌄	Used to display the previous stored channel.	–
0 to 9	Used to display the corresponding channels.	
–/––	Used to select a channel numbered ten or over. Press this button, and the "**P––**" symbol is displayed. Enter the two-digit channel number.	
PRE-CH	Used to switch repeatedly between the last two channels displayed.	
⊕	Used to increase the volume.	–
⊖	Used to decrease the volume.	–
MUTE	Used to switch the sound off temporarily. ➢ To turn the sound back on, press this button again, or ⊕ or ⊖ button.	
MENU	Used to display the on-screen menu system.	Used to return to the previous menu or normal viewing.
▲▼◀▶	–	Used to... ◆ Display a submenu containing selections for the current menu option. ◆ Increase/reduce a menu option value.
ENTER	–	Used to confirm your choice.



Plug and Play Feature

ENG



When the television is initially powered on, several basic customer settings proceed automatically and subsequently. The following settings are available.

1 If the television is in Standby mode, press the **POWER** (⏻) button on the remote control.

Result: The **Plug & Play** is displayed.

2 To start the Plug & Play, press the **ENTER** button.

Result: The **Language** menu is displayed.

3 Select the appropriate language by pressing the ▼ or ▲ button. Press the **MENU** button to confirm your choice.

Result: The message **Antenna input check** is displayed.

4 Make sure that the antenna is connected to the TV. Press the **MENU** button

Result: The **Time** menu is displayed with **Clock** is selected.

5 Press the ◄ or ► button to move to the hour or minute. Set the hour or minute by pressing the ▼ or ▲ button.

Result: Refer to “Setting the Current Date and Time” on page 28.

6 When the setting has finished all, the message **Enjoy viewing your new TV** is displayed.

ENG

Plug and Play Feature

If you want to reset this feature...



1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Plug & Play**.

5 Press the ◄ or ► button.

Result: This feature starts with the message **Plug & Play** is displayed.

Choosing Your Language

When you start using your television for the first time, you must select the language which will be used for displaying menus and indications.



1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the ◄ or ► button.

Result: The **Language** is selected.

4 Select the appropriate language by pressing the ◄ or ► button repeatedly.

Storing Channels Automatically

ENG



You can scan for the frequency ranges available to you (and availability depends on your country). Automatically allocated programme numbers may not correspond to actual or desired programme numbers. However you can sort numbers manually and clear any channels you do not wish to watch.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Channel**.

Result: The options available in the **Channel** group are displayed.

3 Press the ◄ or ► button.

Result: The **Auto Store** is selected.

4 Press the ◄ or ► button to start the search.

Result: The channels are stored in an order which reflects their positions in the frequency range. Finally, the search will end automatically. (depending on the model).

➢ To stop the search before it has finished or return to normal viewing, press the **MENU** button.

5 When the channels have been stored, you can:

- Clear a channel (refer to page 19)
- Fine tune channel reception if necessary (refer to page 20)
- Sort them in the order required (refer to page 21)

Storing Channels Manually

ENG

You can store the television channels, including those received via cable networks.

When storing channels manually, you can choose:

- ***Whether or not to store each of the channels found***
- ***The programme number of each stored channel which you wish to identify***

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Channel**.

Result: The options available in the **Channel** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Manual Store**. Press the ◄ or ► button.

Result: The **Manual Store** menu is displayed with the **Color System** is selected.

5 If necessary, select the broadcasting standard required by pressing the ◄ or ► button repeatedly.

Result: The color standards are displayed in the following order (depending on the model).

- **AUTO – PAL – SECAM – NTSC4.43**
- **AUTO – PAL – SECAM – NTSC4.43 – NTSC3.58**

6 Press the ▼ or ▲ button to select **Sound System**. Press the ◄ or ► button repeatedly.

Result: The sound standards are displayed in the following order (depending on the model).

- **B/G – I – D/K – L/L'**
- **B/G – I – D/K – M**



Storing Channels Manually (continued)

ENG





7 If you do not know the channel numbers, select **Search** by pressing the ▼ or ▲ button. Press the ◄ or ► button to start the search.

Result: The tuner scans the frequency range until the first channel or the channel that you selected is received on your screen.

8 To assign a programme number to a channel, select **Prog.No.** by pressing the ▼ or ▲ button. Press the ◄ or ► button to find the correct number.

9 To store the channel and associated programme number, select **Store** by pressing the ▼ or ▲ button. Set to **OK** by pressing the ◄ or ► button.

10 Repeat Steps **7** to **9** for each channel to be stored.

Channel mode

- **P** (Programme mode): When completing tuning, the broadcasting stations in your area have been assigned to position numbers from P00 to max P99. You can select a channel by entering the position number in this mode.
- **C** (Real channel mode): You can select a channel by entering the assigned number to each air broadcasting station in this mode.
- **S** (Cable channel mode): You can select a channel by entering the assigned number for each cable channel in this mode.

Skipping Unwanted Channels

ENG

You can exclude the channels of your choice from the channel scan operation. When you scan through the stored channels, those that you have chosen to skip are thus not displayed. All channels that you do not specifically choose to skip are displayed during scanning.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Channel**.

Result: The options available in the **Channel** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Add/Erase**. Press the ◄ or ► button.

Result: The current channels are displayed.

5 Press the ▼ or ▲ button to select the channel to add or erase. Select **Erased** or **Added** by pressing the ◄ or ► button.

6 Repeat Step **5** for each channel to be added or erased.



Fine Tuning Channel Reception

ENG





If the reception is clear, you do not have to fine tune the channel, as this is done automatically during the search and store operation. If the signal is weak or distorted, you may have to fine tune the channel manually.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Channel**.

Result: The options available in the **Channel** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Fine Tune**. Press the ◄ or ► button.

Result: The **Fine Tune** menu is displayed with the **Tune** is selected.

5 To obtain a sharp and clear picture and good sound quality, press the ◄ or ► button.

Result: The horizontal bar is displayed. Move the horizontal bar's cursor left or right by pressing the ◄ or ► button.

6 To memorise adjusted picture or sound, select **Store** by pressing the ▼ or ▲ button. Press the ◄ or ► button.

Result: **OK** is displayed.

7 To erase adjusted picture or sound, select **Erase** by pressing the ▼ or ▲ button. Press the ◄ or ► button.

Result: **OK** is displayed.

Sorting the Stored Channels

ENG

This operation allows you to change the programme numbers of stored channels. This operation may be necessary after using auto store. You can delete the channels you do not want to keep.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Channel**.

Result: The options available in the **Channel** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Sort**. Press the ◄ or ► button.

Result: The **Sort** menu is displayed with the **From** is selected.

5 Select the channel number that you wish to change by pressing the ◄ or ► button repeatedly.

6 Press the ▼ or ▲ button to select **To**. Select the new channel number which you wish to identify by pressing the ◄ or ► button repeatedly.

7 Press the ▼ or ▲ button to select **Store**. Select **OK** to confirm the exchange of channel numbers by pressing the ◄ or ► button.

Result: The selected channel is exchanged with the one previously stored to the chosen number.

8 For all the channels to move to the required channel numbers, repeat steps **5** to **7** after selecting the **From** by pressing the ▼ or ▲ button.







Activating the Child Lock

ENG

This feature allows you to lock the television so that it cannot be switched on via the front panel. It can, however, still be switched on via the remote control. Thus, by keeping the remote control away from unauthorised users, such as children, you can prevent them from watching unsuitable programme.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Channel**.

Result: The options available in the **Channel** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Child Lock**. Press the ◄ or ► button.

5 To activate this feature, select **On** by pressing the ◄ or ► button.

6 Press the ▼ or ▲ button to select **Prog.No.**. Select the number of the programme to which the channel is to be locked by pressing the ◄ or ► button.

7 Press the ▼ or ▲ button to select **Lock**. Select **Locked** by pressing the ◄ or ► button.

ENG

Displaying Information

You can display various types of information on the screen to help you use your television.

Press the **INFO** button to display the information. To remove the information from the screen, press the **INFO** button again.

➢ When a tray is present in the DVD, even if it is stopped, the same information is displayed in television mode as in the DVD mode.

Changing the Picture Standard

You can select the type of picture which best corresponds to your viewing requirements.



1 Press the **MENU** button.

Result: The options available in the **Picture** group are displayed.

2 Press the ◀ or ▶ button.

Result: The **Mode** is selected.

3 Select the required picture effect by pressing the ◀ or ▶ button repeatedly.

Result: The following picture effects are available: **Dynamic** – **Standard** – **Movie** – **Custom**.

Adjusting the Picture Settings

ENG









Your television has several settings which allow you to control picture quality.

1 Press the **MENU** button.

Result: The options available in the **Picture** group are displayed.

2 Press the ◀ or ▶ button.

3 Press the ▼ or ▲ button to select **Adjust**. Press the ◀ or ▶ button.

Result: The **Adjust** menu is displayed.

4 Press the ▼ or ▲ button to select the option to be adjusted (**Contrast**, **Brightness**, **Sharpness**, **Color**, or **Tint**-NTSC only). Press the ◀ or ▶ button.

Result: The horizontal bar is displayed. Move the horizontal bar's cursor left or right by pressing the ◀ or ▶ button.

5 Press the **MENU** button.

Result: The options available in the **Picture** group are displayed again.

6 Press the ▼ or ▲ button to select **Color Tone**. Press the ◀ or ▶ button repeatedly.

Result: The color tones are displayed in the following order.

Normal – Warm 1 – Warm 2 – Cool 2 – Cool 1

➢ If you make any changes to these settings, the picture mode is automatically switched to **Custom**.

ENG

Selecting the Picture Size (depending on the model)

You can select the picture size which best corresponds to your viewing requirements.



1 Press the **MENU** button.

Result: The options available in the **Picture** group are displayed.

2 Press the ◀ or ▶ button.

3 Press the ▼ or ▲ button to select **Size**. Press the ◀ or ▶ button repeatedly.

Result: The picture sizes are displayed in the following order

- **Normal – Zoom**

➢ You can select these options by simply pressing the **ZOOM** button on the remote control.



Activating/Deactivating the Digital Noise Reduction Feature

If the broadcast signal received by your television is weak, you can activate this feature to reduce any static and ghosting that may appear on the screen.



1 Press the **MENU** button.

Result: The options available in the **Picture** group are displayed.

2 Press the ◀ or ▶ button.

3 Press the ▼ or ▲ button to select **Digital NR**.

4 To activate this feature, select **On** by pressing the ◀ or ▶ button.

Viewing Pictures From External Sources

ENG



Once you have connected up your various audio and video systems, you can view different sources by selecting the appropriate input. You can select these options by simply pressing the INPUT ( ) button on the remote control.

1	Press the **MENU** button. Result: The main menu is displayed.
2	Press the ▼ or ▲ button to select **Function**. Result: The options available in the **Function** group are displayed.
3	Press the ◀ or ▶ button.
4	Press the ▼ or ▲ button to select **TV/AV/DVD**.
5	Press the ◀ or ▶ button to change the setting.

➢
- Depending on the source selected, the pictures may appear automatically.
- To watch television programme again, press the **INPUT** button and select the number of the channel required.
- To connect different types of video equipment to your television, use the input connectors on the side and rear panels (RCA and SCART respectively).
  If equipment is plugged into both these connectors, the side connector has priority.

Setting the Blue Screen



If no signal is being received or the signal is very weak, a blue screen automatically replaces the noisy picture background.

If you wish to continue viewing the poor picture, you must set the "Blue Screen" mode to "Off".

1	Press the **MENU** button. Result: The main menu is displayed.
2	Press the ▼ or ▲ button to select **Function**. Result: The options available in the **Function** group are displayed.
3	Press the ◀ or ▶ button.
4	Press the ▼ or ▲ button to select **Blue Screen**.
5	Press the ◀ or ▶ button to change the setting (**Off** or **On**).

ENG

Changing the Sound Standard

You can select the type of special sound effect to be used when watching a given broadcast.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Sound**.

Result: The options available in the **Sound** group are displayed.

3 Press the ◄ or ► button.

Result: The **Mode** is selected.

4 Select the required sound effect by pressing the ◄ or ► button repeatedly.

Result: The following sound effects are available: **Standard** – **Music** – **Movie** – **Speech** – **Custom**.



Adjusting the Sound Settings

The sound settings can be adjusted to suit your personal preferences.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Sound**.

Result: The options available in the **Sound** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Adjust**. Press the ◄ or ► button.

5 Press the ▼ or ▲ button to select the option to be adjusted. Adjust to satisfy your preference by pressing the ◄ or ► button.





Setting the Current Date and Time

ENG







You can set the current date and time so that they are displayed by pressing the "DISPLAY" button. You must also set the time if you wish to use the automatic on or off timers.

➢ When pressing the " **I** " button (On/Off) on the front of the television, the date and clock setting will be reset.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the ◀ or ▶ button.

4 Press the ▼ or ▲ button to select **Time**. Press the ◀ or ▶ button.

Result: The **Time** menu is displayed with the **Clock** is selected.

5 To set the usery time, press the ◀ or ▶ button to move to the hour or minute.
Set these by pressing the ▼ or ▲ button.

Switching the Television On and Off Automatically

ENG

You can set the On/Off timers so that the television will:

- ***Switch on automatically and tune to the channel of your choice at the time you select***
- ***Switch off automatically at the time you select***

➢ The first step is to set the television's clock (refer to "Setting the Current Date and Time" on page 28). If you have not yet set the clock, you can not set the timers.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the ◄ or ► button.

4 Press the ▼ or ▲ button to select **Time**. Press the ◄ or ► button.

Result: The **Time** menu is displayed.

5 Press the ▼ or ▲ button to select **Timer**. Select **On** by pressing the ◄ or ► button

Result: The **On Time** and **Off Time** options are displayed.

➢ If you have not yet set the clock, the message **Set the clock first** is displayed.

6 To switch on automatically, select **On Time** by pressing the ▼ or ▲ button. Press the ◄ or ► button to move to the hour or minute. Set these by pressing the ▼ or ▲ button.

7 In the same way, set the **Off Time** to switch off automatically.











ENG

Setting the Sleep Timer

You can select a time period of between 30 and 180 minutes after which the television automatically switches to Standby mode.

1 Press the **SLEEP** button.

Result: If the sleep timer is not yet set, **Off** is displayed. If the sleep timer is already set, the remaining time before which the television switches to Standby mode is displayed.

2 Select the preset time intervals (30, 60, 90, 120, 150, 180) by pressing the **SLEEP** button repeatedly.

Result: The television automatically switches to Standby mode when the timer reaches 0.

- After setting the sleep timer, you can display and modify the remaining time by pressing the **SLEEP** button again. To switch the sleep timer off, select **Off**.
- Your television switches to Standby mode automatically fifteen minutes after the last broadcast has finished on the selected channel.

Locking the Front Panel



The television panel can be locked to prevent it from being used by young children for example.
The Panel Lock function is cancelled when the master switch is turned on/off or when the power cord is disconnected.

1 Press the **MENU** button.

Result: The main menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the ◀ or ▶ button.

4 Press the ▼ or ▲ button to select **Panel Lock**.

5 Select **On** by pressing the ◀ or ▶ button.

Playing a Disc

ENG

Play

1 Press the **TV ↔ DVD** button to switch the DVD mode.

2 Press the **OPEN/CLOSE** (⏏) button.

3 Press the **PLAY/PAUSE** (▶II) or **OPEN/CLOSE** (⏏) button to close the disc tray.



☛ ***RESUME function***

When you stop disc play, the player remembers where you stopped, so when you press the **PLAY/PAUSE** (▶II) again, it will pick up where you left off (unless the disc is removed, the **STOP** (■) button is pressed twice or the set is unplugged.).



➢
- If the player is left for 5 minutes in pause mode, it will stop.
- This ⊘ icon indicates an invalid button press.

Stopping Play

Press the **STOP** (■) button during play.

Removing Disc

Press the **OPEN/CLOSE** (⏏) button.

Pausing Play

Press the **PLAY/PAUSE** (▶II) during playback.

- Screen stops, no sound.
- To resume again, press the **PLAY/PAUSE** (▶II) button once again.

Slow Motion Play (Except CD)

Press the **FF** (▶▶) button for move than 1 second during Pause or Step mode.

- By pressing the **FF** (▶▶) button for move than 1 second, you can select slow motion play for 1/2, 1/4, 1/8 or 1/16 of normal speed.
- No sound is heard during slow mode.
- Press the **PLAY/PAUSE** (▶II) button to resume normal play.
- When playing a VCD the reverse slow motion play will not work.

Playing a Disc (MP3/WMA)

ENG



1. Press the **OPEN/CLOSE** (⏏) button. Place a disc gently into the tray with the disc's label facing up. Press the **PLAY/PAUSE** (▶II) or **OPEN/CLOSE** (⏏) button to close the disc tray.
2. Press the ▼ or ▲ button to select the desired music folder, then press the **ENTER** or ▶ button.
3. Press the ▼ or ▲ button again to select a song file. Press the **ENTER** or **PLAY/PAUSE** (▶II) button to begin play of the song file.
4. To play another song file of the same music folder, press the **STOP** (■) button and press the ▼ or ▲ button to select a song file. Press the **ENTER** or **PLAY/PAUSE** (▶II) button.
   To play another song file of another folder, press the ◀ button to move the music folder lists. Repeat Steps **2** to **3**.

When playing CD-R/MP3 discs, please follow the recommendations below:

- **Your MP3 files should be ISO 9660 or JOLIET format.**
  ISO 9660 format and Joliet MP3 files are compatible with Microsoft's DOS and Windows, and with Apple's Mac. These two formats are the most widely used.
- **When naming your MP3 files do not exceed 8 characters, and place ".mp3" as the file extension.**
  General name format of: Title.mp3. When composing your title, make sure that you use 8 characters or less, have no spaces in the name, and avoid the use of special characters including: (.,/,\,=,+).
- **Use a decompression transfer rate of at least 128 Kbps when recording MP3 files.**
  Sound quality with MP3 files basically depends on the rate of compression/decompression you choose. Getting audio CD quality sound requires an analog/digital sampling rate (conversion to MP3 format) of at least 128 Kbps and up to 160 Kbps. However, choosing higher rates, like 192 Kbps or more, only rarely give better sound quality. Conversely, files with sampling rates below 128 Kbps will not be played properly.
- **Do not try recording copyright protected MP3 files.**
  Certain "securized" files are encrypted and code protected to prevent illegal copying. These files are of the following types: Windows Media™ (registered trade mark of Microsoft Inc) and SDMI™ (registered trademark of The SDMI Foundation). You cannot copy such files.
- **Your DVD player only accepts one level of file directory.**
  Consequently you must choose:
  - either to save all your MP3 recording files at the root of the disc;
  - and/or create folders in the directory for each artist or music type (e.g.classical, rock, jazz, etc)
- **Important:** The above recommendations cannot be taken as a guarantee that the DVD player will play MP3 recordings, or as an assurance of sound quality. You should note that certain technologies and methods for MP3 file recording on CD-Rs prevent optimal playback of these files on your DVD player (degraded sound quality and in some cases, inability of the player to read the files).
- This unit can play a maximum of 500 files and 300 folders per disc.

Playing a Disc (MPG)

ENG

1 Press the **OPEN/CLOSE** (⏏) button. Place a disc gently into the tray with the disc's label facing up. Press the **PLAY/PAUSE** (▶II) or **OPEN/CLOSE** (⏏) button to close the disc tray.

2 Press the ▼ or ▲ button to select the desired MPEG folder, then press the **ENTER** or ▶ button.

3 Press the ▼ or ▲ button again to select a MPEG file. Press the **ENTER** or **PLAY/PAUSE** (▶II) button to begin play of the MPEG file.

4 To play another MPEG file of the same MPEG folder, press the **STOP** (■) button and press the ▼ or ▲ button to select a MPEG folder. Press the **ENTER** or **PLAY/PAUSE** (▶II) button.
To play another MPEG folder of another folder, press the ◀ button to move the MPEG folder lists. Repeat Steps **2** to **3**.







Playing a Disc (Picture CD)

ENG





Press the **OPEN/CLOSE** (⏏) button. Place a disc gently into the tray with the disc's label facing up. Press the **PLAY/PAUSE** (▶II) or **OPEN/CLOSE** (⏏) button to close the disc tray.

Rotating and Reversing the picture

1 Press the ▼ or ▲ button to select the desired picture file of the file list, then press the **ENTER** button.

Result: The selected picture is displayed.

➢ If you want to return to the file list, press the **STOP** (■) button.

2 Press the ◄ or ► button to rotate the picture.

3 Press the ▲ button repeatedly to reverse vertically.
Press the ▼ button repeatedly to reverse horizontally.

Slide Show

Press the ▼ or ▲ button to select the desired picture file of the file list, then press the **PLAY/PAUSE** (▶II) button.

Result: It enters slide show mode.

➢ If you want to return to the file list, press the **STOP** (■) button.

Viewing the Album Screen

1 Press the **DVD MENU** button during slide show.

Result: The DVD menu is displayed with the **Disc Menu** is selected.

2 Press the **ENTER** button.

Result: It enters album screen mode.

3 To display the next or previous 12 pictures, press the ▶▶I (next skip) or I◀◀ (back skip) button.

4 Press the ▼, ▲, ◄, or ► button to select the desired picture, then press the **PLAY/PAUSE** (▶II) button.

Result: It enters slide show mode again.

➢ If you press the **ENTER** button after selecting the desired picture, the selected picture will be displayed only.

Using the Search and Skip Functions

ENG

Searching through a Chapter or Track

Press the **FF** (▶▶) or **REW** (◀◀) button during play.

- Press the **FF** (▶▶) or **REW** (◀◀) button for move than 1 second and press again or press continuously to search at a faster speed on the DVD (2X/4X/8X/16X/ 32X), VCD (2X/4X/8X/16X/ 32X), or CD (2X/4X/8X/16X/ 32X).
- To return to normal speed playback, press the **PLAY/PAUSE** (▶II) button.

Skipping Tracks

During play, press the ▶▶I (next skip) or I◀◀ (back skip) button.

- When playing a DVD, if you press the ▶▶I (next skip) button, it moves to next chapter. If you press the I◀◀ (back skip) button, it moves to the beginning of the chapter. One more press makes it move to the beginning of the previous chapter.
- When playing a CD, if you press the ▶▶I (next skip) button, it moves to next track. If you press the I◀◀ (back skip) button, it moves to the beginning of the track. One more press makes it move to the beginning of the previous track.
- When playing a VCD 2.0 in MENU OFF mode, a VCD1.1 or a CD, if you press the ▶▶I (next skip) button, it moves to next track. If you press the I◀◀ (back skip) button, it moves to the the beginning of the track. One more press makes it move to the beginning of the previous track.
- If a track exceeds 15 minutes when playing a VCD and you press the ▶▶I (next skip) button, it moves forward 5 minutes. If you press the I◀◀ (back skip) button, it moves backward 5 minutes.
- When playing a VCD 2.0 in the MENU MODE or Track View function, if you press the ▶▶I (next skip) button, it moves to the next menu or the next Track View display. If you press the I◀◀ (back skip) button, it moves to the previous menu or the previous Track View display.



➢
- When in search mode (2X/4X/8X/16X/32X) on a DVD or high-speed playback on a VCD, no sound will be heard.
- When 2X SCAN AUDIO is set to ON in the SETUP MENU, no sound will be heard on discs which are recorded with PCM, DTS or MPEG-2.
- Depending on the disc, audio may not be heard when a disc is in 2X playback mode.

ENG

Using the Disc Menu



1 Press the **DVD MENU** button during the play of a DVD.

Result: The DVD menu is displayed with the **Disc Menu** is selected.

2 Press the **ENTER** button.

➢ Depending on the disc, the **Disc Menu** may not work.

Using the Title Menu



1 Press the **DVD MENU** button during the play of a DVD.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Title Menu**.

3 Press the **ENTER** button.

➢
- Depending on the disc, the **Title Menu** may not work.
- The **Title Menu** will only be displayed if there are at least two titles in the disc.

Displaying the Disc Information

ENG

1 Press the **DVD MENU** button during play.
Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.
Result: The options available in the **Function** group are displayed.

3 Press the **ENTER** button.
Result: The **Info** menu is selected.

4 Press the **ENTER** button again.
Result: Depending on the disc, the disc information will be displayed.
➢ You can display by simply pressing the **INFO** button on the remote control.

5 Press the ▼ or ▲ button to select the required item. Press the ◄ or ► button to make the required setup, then press the **ENTER** button.
➢ You may use the number buttons of the remote control to start play from a desired time.

6 To make the screen disappear, press the **INFO** button.



Title — To access the desired title when there is more than one in the disc. For example, if there is more than one movie on a DVD, each movie will be identified.

Chapter — Most DVD discs are recorded in chapters so that you can quickly find a specific passage.

Time — Allows playback of the film from a desired time. You must enter the starting time as a reference.

Audio — Refers to the language of the film soundtrack. In the example, the soundtrack is played in English 5.1CH. A DVD disc can have up to eight different soundtracks.

Subtitle — Refers to the subtitle languages available in the disc. You will be able to choose the subtitles language or, if you prefer, turn them off from the screen. A DVD disc can have up to 32 different subtitles.

3D Sound — The simulated surround effect depends on the disc contents. If you connect the unit to your stereo system, you can enhance sound quality and produce a greater surround effect. This feature is useful when you are using the DVD player with a two channel stereo through the analog outputs. (Discs which are recorded with PCM or DTS will not work.)
3D Sound is possible only on discs recorded using DOLBY SURROUND or DOLBY DIGITAL. However, some of these discs do not contain rear channel sound signals. Depending on the disc, the 3D Sound function may not work.

➢
- **Chapter?** Each Title on a DVD is usually divided into chapters (similar to tracks on an audio CD).
- **Title?** A DVD may contain several different titles. For example, if a disc contains four different movies, each might be considered a title.

Using the Zoom Function (DVD/VCD)

ENG



1 Press the **DVD MENU** button during play or pause mode.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Zoom**. Press the **ENTER** button.

Result: The " " mark is displayed.

➢ You can display by simply pressing the **ZOOM** button on the remote control.

5 Press the **ENTER** button repeatedly to zoom in on.

– DVD or VCD: 2X, 3X, 4X, 1/2X, 1/3X, 1/4X in order.

6 Press the ▼, ▲, ◄, or ► button to select the part of the screen you want to zoom in on (2X/3X/4X).

Using the Bookmark Function (DVD/VCD)

ENG

This feature lets you bookmark sections of a DVD or VCR so you can quickly find them at a later time.



1 Press the **DVD MENU** button during play.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.



3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Bookmark**. Press the **ENTER** button.

5 Press the ◄ or ► button to move to the desired bookmark icon.

6 When you reach the scene you want to mark, press the **ENTER** button.

Result: The icon will change to a number (1, 2, or 3).

Recalling a Marked Scene

Press the ◄ or ► button to select a marked scene. Press the **PLAY/PAUSE** (►II) button to skip to the marked scene.

Clearing a Bookmark

Press the ◄ or ► button to select the bookmark number you want to delete. Press the **CLEAR** button to delete a bookmark number.

➢ ◆ Up to three scenes may be marked at the same time.

◆ Depending on the disc, this function may not work.

Repeat Play

ENG



Repeat the current track, chapter, title, a chosen section (A-B), or all of the disc .

1	Press the **DVD MENU** button during play. Result: The DVD menu is displayed.
2	Press the ▼ or ▲ button to select **Function**. Result: The options available in the **Function** group are displayed.
3	Press the **ENTER** button.
4	Press the ▼ or ▲ button to select **Repeat**. Press the **ENTER** button. ➢ You can display by simply pressing the **REPEAT** button on the remote control.
5	Press the ◄ or ► button to select the chapter, title or A-B. Press the **ENTER** button.

DVD



A-B Repeat

1	Press the ◄ or ► button to select **A-**. Press the **ENTER** button at the point where you want the repeat play to start.
2	Press the ◄ or ► button to select **B**. Press the **ENTER** button at the point where you want the repeat play to stop.
3	To return to normal play, press the ◄ or ► button to select **Off** and press the **ENTER** button.

VCD/CD

➢
- The DVD repeats play by chapter or title, the CD and VCD repeat play by track or disc.
- Depending on the disc, this function may not work.
- If the title or track is completed before marking the end (**B**), the end of title or track becomes **B** automatically.

Using the EZ View (depending on the Disc)

ENG

You can adjust the screen setting (aspct ratio) which best corresponds to your viewing requirements.



1 Press the **DVD MENU** button during play.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **EZ View**. Press the **ENTER** button.

5 Select the appropriate option (**Wide**, **Screen Fit**, **Normal/LB**, or **Normal/PS**) by pressing the ◄ or ► button.

- **Wide, Normal/LB, Normal/PS**
  Refer to page 45.

- **SCREEN FIT**
  The top and bottom of the screen are cut off.
  When playing a 2.35:1 aspect ratio disc, the black bars at top and bottom of the screen will disappear. The picture will look vertically stretched. (Depending on the type of disc, the black bars may not disappear completely.)

Program Play (CD)

ENG







1 Press the **DVD MENU** button during play.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Function**.

Result: The options available in the **Function** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Program**. Press the **ENTER** button..

5 Press the numeric buttons to select the first track to add to the program.

Result: Selected numvers are displayed in the first track.

6 Press the ▼, ▲, ◄ or ► button to move the next tray. Follow the above instruction for programming.

7 Press the **PLAY/PAUSE** (►II) button.

Result: The disc will be played in programmed order.

➢
- ◆ Depending on the disc, this function may not work.
- ◆ Press the STOP button twice to cancel Program Play during playback.
- ◆ Opening the tray by pressing the OPEN/CLOSE button cancels Program Play.

Changing the Camera Angle



When a DVD contains multiple angles of a particular scene, you can select the Angle function.

Press the **ANGLE** button. Press the ◄ or ► button to select the desired screen angle. To turn off the display, press the **ANGLE** button again.

Setting up the Language Features

ENG

If you set the player menu, disc menu, audio and subtitle language in advance, they will come up automatically every time you watch a movie.

1 Press the **DVD MENU** button.
Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Setup**.
Result: The options available in the **Setup** group are displayed.

3 Press the **ENTER** button.
Result: The **Language Setup** menu is selected.

4 Press the **ENTER** button again.
Result: The options available in the **Language Setup** group are displayed.

5 Press the ▼ or ▲ button to select the required menu (**Player Menu**, **Disc Menu**, **Audio**, or **Subtitle**). Press the **ENTER** button.

6 Select the appropriate language by pressing the ▼ or ▲ button. Press the **ENTER** button.

- **Player Menu**
  Use the Player preference menu to select the language for the player's on-screen displays.
- **Disc Menu**
  Use the Menu preference menu to select the language you want a DVD's disc menu to be displayed in.
  – Select **Others** if the language you want is not listed.
- **Audio**
  Use the Audio preference menu to select the sound-track language.
  – Select **Original** if you want the default soundtrack language to be the original language the disc is recorded in.
  – Select **Others** if the language you want is not listed.
- **Subtitle**
  Use the Subtitle preference menu to select the language the disc's subtitles are to be displayed in.
  – Select **Automatic** if you want the subtitle language to be the same as the language selected as the audio preference.
  – Select **Others** if the language you want is not listed. Some discs may not contain the language you select as your initial language; in that case the disc will use its original language setting.

➢
- This function depends on what languages are encoded on the disc and may not work with all DVDs.
- If the selected language is not recorded on the disc, the original pre-recorded language is selected.











Setting up the Audio Options

ENG







If you set the player menu, disc menu, audio and subtitle language in advance, they will come up automatically every time you watch a movie.

1 Press the **DVD MENU** button.
Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Setup**.
Result: The options available in the **Setup** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Audio Setup**. Press the **ENTER** button.
Result: The options available in the **Audio Setup** group are displayed.

5 Press the ▼ or ▲ button to select the required menu (**Digital Output**, **DTS**, or **Dynamic Compression**).

6 Select the appropriate option by pressing the ◄ or ► button.

- **Digital Output : Off**, **Bitstream**, **PCM**
  - Select **Bitstream** when using the Digital Audio Output. Converts to Dolby Digital Bitstream - 5.1CH (in case of MPEG-2, 5.1CH or 7.1CH).
  - Select **PCM** when using the Analog Audio Outputs. Converts to PCM(2CH) audio.
- **Dynamic Compression**
  - **Off :** To select the standard range.
  - **On :** To select dynamic compression.

➢
- Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.
- "DTS" and "DTS Digital Out" are trademarks of Digital Theater Systems, Inc.

Setting up the TV Aspect

ENG

You can adjust the screen setting (aspect ratio) which best corresponds to your viewing requirements.

1 Press the **DVD MENU** button.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Setup**.

Result: The options available in the **Setup** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Display Setup**. Press the **ENTER** button.

Result: The options available in the **Display Setup** group are displayed with the **TV Aspect** selected.

5 Press the **ENTER** button.

6 Select the required aspect by pressing the ▼ or ▲ button. Press the **ENTER** button.

- **4:3 Letter Box**
  Select when you want to see the total 16:9 ratio screen DVD supplies. Black bars will appear at the top and bottom of the screen.
- **4:3 Pan Scan**
  Select this for conventional size TVs when you want to see the central portion of the 16:9 screen. (Extreme left and right side of movie picture will be cut off.)
- **16:9 Wide**
  You can view the full 16:9 picture on your wide screen TV.







Setting up the Display Options

ENG









1 Press the **DVD MENU** button.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Setup**.

Result: The options available in the **Setup** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Display Setup**. Press the **ENTER** button.

Result: The options available in the **Display Setup** group are displayed.

5 Press the ▼ or ▲ button to select the required menu (**Screen Messages**, **Black Level**, or **NTSC Disc Output**).

6 Select the appropriate option by pressing the ◄ or ► button.

- **Screen Messages : On** or **Off**.
  Use to turn on-screen messages on or off.
- **Black Level : On** or **Off**.
  Adjusts the brightness of the screen.
- **NTSC Disc Output**
  When outputting the NTSC Disc to the external device of NTSC system, select **NTSC**. For the PAL system, select **PAL**. Otherwise, there may be no color or abnormal color.

Setting up the Parental Control

ENG

1 Press the **DVD MENU** button.

Result: The DVD menu is displayed.

2 Press the ▼ or ▲ button to select **Setup**.

Result: The options available in the **Setup** group are displayed.

3 Press the **ENTER** button.

4 Press the ▼ or ▲ button to select **Parental Setup**. Press the **ENTER** button.

Result: The **Enter Password** is displayed.

5 Enter the default password (**0000**) by using the numeric buttons.

Result: The options available in the **Parental Setup** group are displayed with the **Use Password** selected.

➢ If you have lost your password, enter the master password (**1369**).

6 Select **Yes** by pressing the ► button to use a password.

Result: The **Rating Level** and **Change Password** are displayed.

7 **About the Rating Level;**

1. Press the ▼ or ▲ button to select **Rating Level**. Press the **ENTER** button.
2. Press the ▼ or ▲ button to select the level (e.g. **Level 8**) and press the **ENTER** button.
   Discs that contain Level 7 will now not play.

➢ To cancel the rating level, select **No** in the **Use Password** pressing the ► button.

8 **About the Change Password;**

1. Press the ▼ or ▲ button to select **Change Password**. Press the **ENTER** button.
   Result: The **Enter New Password** is displayed.
2. Enter your new password.
   Result: The **Re-enter New Password** is displayed.
3. Enter your new password again to confirm.













Teletext Feature

ENG



Most television channels provide written information services via teletext. Information provided includes:

- ***Television programme times***
- ***News bulletins and weather forecasts***
- ***Sports results***
- ***Travel information***

This information is divided into numbered pages (see diagram).

Part	Contents
A	Selected page number.
B	Broadcasting channel identity.
C	Current page number or search indications.
D	Date and time.
E	Text.
F	Status information. FASTEXT information.

➢ Teletext information is often divided between several pages displayed in sequence, which can be accessed by:

- Entering the page number
- Selecting a title in a list
- Selecting a coloured heading (FASTEXT system)

Displaying the Teletext Information

ENG

You can display Teletext information at any time on your television.

☛ For Teletext information to be displayed correctly, channel reception must be stable; otherwise:
- Information may be missing
- Some pages may not be displayed



1	Select the channel providing the Teletext service using the **P**⌃ or **P**⌄ button.
2	Press the **TV/TTX/MIX** button to activate the teletext mode. Result: The contents page is displayed. It can be redisplayed at any time by pressing the (index) button.
3	Press the **TV/TTX/MIX** button. Result: The screen will be split into two. This Double Teletext feature lets you view the actual broadcast and teletext information separately on the screen.
4	If you wish to display the actual broadcast at the same time as the teletext page, press the **TV/TTX/MIX** button again.
5	Press the **TV/TTX/MIX** button to exit from the teletext display.

Selecting Display Options

ENG





When you have displayed a Teletext page, you can select various options to suit your requirements.

To display...	Press the...
◆ Hidden text (answers to quiz games, for example)	(reveal)
◆ The normal screen	(reveal) again
◆ The next page	(page up)
◆ The previous page	(page down)
◆ Double-size letters in the: • Upper half of the screen • Lower half of the screen	(size) • Once • Twice
◆ Normal screen	• Three times

Selecting a Teletext Page

ENG

You can enter the page number directly by pressing the numeric buttons on the remote control.



1 Enter the three-digit page number given in the content by pressing the corresponding numeric buttons.

Result: The current page counter is incremented and the page is then displayed. If the selected page is linked with several secondary pages, the secondary pages are displayed in sequence. To freeze the display on a given page, press the (hold). Press the it again to resume.

2 If the FASTEXT system is used by the broadcasting company, the different topics covered on a Teletext page are colour-coded and can be selected by pressing the coloured buttons on the remote control.
Press the coloured button corresponding to the topic that you wish to select; the available topics are given on the status line.

Result: The page is displayed with other colored information that can be selected in the same way.

3 To display the previous or next page, press the corresponding coloured button.

4 When you have finished, press the **TV/TTX/MIX** button to return to your normal broadcast.

Storing Teletext Pages

ENG



You can store up to four teletext pages to display them later at leisure.

1 Select the LIST mode using the button.

Result: Four 3-digit numbers are displayed in different colours.

➢ The button is used to switch between the **LIST** and **FLOF** modes.

2 Press the coloured button corresponding to the page that will be replaced.

3 Enter the new page number using the numeric buttons.

4 Repeat steps **2** and **3** for each page to be stored, using a different coloured button each time.

5 Press the (store) button until the corresponding blocks blink.

Connecting to the External Input/Output

ENG

"⇥1" is used for the equipment with an RGB output, such as video game devices or video disc players.

Rear of the TV







① This end can be fitted with:
- A SCART connector
- Three RCA connectors (VIDEO + AUDIO-L/R)

➢ Be sure to turn OFF the SCART device to connect to the side AV input Port.

Connecting to the Digital Audio Outputs

The DIGITAL AUDIO OUT (COAXIAL/OPTICAL) connectors are used for equipment, such as an audio system (to take full advantage of the Surround sound effect).

Rear of the TV





ENG

Connecting to the Audio/Video Input

The RCA (AUDIO-R/L + VIDEO) connectors are used for equipment such as VCRs, camcorders, video disc players and some video game devices.

Side of the TV





➢ Be sure to turn OFF the SCART device to connect to the side AV input Port.

Connecting Headphones

You can connect a set of headphones to your television if you wish to watch a television programme without disturbing the other people in the room.

➢ Prolonged use of headphones at a high volume may damage your hearing.

Side of the TV



SCART Connector Wiring

ENG

If you wish to connect other equipment via the SCART connectors on your television, contact your dealer or a qualified technician to wire the A/V cable as illustrated below.

Pin	Signal
1	Audio output R
2	Audio input R
3	Audio output L
4	Audio chassis return
5	Video chassis return (RGB blue)
6	Audio input L
7	RGB blue input
8	Switching voltage
9	Video chassis return (RGB green)
10	-
11	RGB green input

Pin	Signal
12	-
13	Video chassis return (RGB red)
14	-
15	RGB red input
16	Blanking signal (RGB switching)
17	Video chassis return
18	Blanking signal ground
19	Video output
20	Video input
21	Screening/chassis return

➢ Pins 5, 7, 9, 11, 13, 15 and 16 are used for RGB processing.

Disc Type and Characteristics

ENG

The DVD player is capable of playing the following types of discs with the corresponding logos:

Disc Types (Logos)	Recording Types	Disc Size	Max. Playing Time	Characteristics
DVD	Audio + Video	5”	Single-sided: 240 min. Double-sided: 480 min.	– DVD contains excellent sound and video due to Dolby Digital and MPEG-2 system. – Various screen and audio functions can be easily selected through the on-screen menu.
		3 1/2”	Single-sided: 80 min. Double-sided: 160 min.	
VIDEO-CD	Audio + Video	5”	74 min.	– Video with CD sound, VHS quality and MPEG-1 compression technology.
		3 1/2”	20 min.	
AUDIO-CD	Audio	5”	74 min.	– CD is recorded as a Digital Signal with better audio quality, less distortion and less deterioration of audio quality over time.
		3 1/2”	20 min.	

Disk Markings

Play Region Number
Both the DVD player and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

NTSC **NTSC broadcast system** in U.S.A, Canada, Korea, Japan, etc.

PAL **PAL broadcast system**

Dolby Digital disc

STEREO **Stereo disc**

DIGITAL SOUND **Digital Audio disc**

DTS disc

MP3

DCDi

Technical Specifications

ENG

The descriptions and characteristics in this booklet are given for information purposes only and are subject to modification without notice.

Model name		15G10
Tube type		4:3
Screen size		15 inch (25.8/18.4 cm)
Colour systems		PAL, SECAM, NTSC4.43 (depending on the model)
TV standards		B/G, I, D/K, L/L' (depending on the model)
Sound		MONO
Audio output power		1.5W x 2
Power supply		230V ~, 50Hz
Power consumption		80 watts
Sockets	Rear	External input/output (**EXT1**) Digital audio outputs (**COAXIAL** / **OPTICAL**)
	Side	Audio/Video inputs (**R**-**AUDIO**-**L** / **VIDEO**) Headphone jack
Demensions (H x W x D)		380 x 400 x 381 mm
Weight		13.7 kg

Troubleshooting: Before Contacting Service Personnel

ENG

Before contacting Samsung after-sales service, perform the following simple checks.

If you cannot solve the problem using the instructions below, note the model and serial number of the television and contact your local dealer.

No sound or picture	◆ Check that the mains lead has been connected to a wall socket. ◆ Check that you have pressed the "**I** " button (On/Off) and the **POWER** (⏻) button. ◆ Check the picture contrast and brightness settings. ◆ Check the volume.
Normal picture but no sound	◆ Check the volume. ◆ Check whether the volume **MUTE** (🔇) button on the remote control has been pressed.
No picture or black and white picture	◆ Adjust the colour settings. ◆ Check that the broadcast system selected is correct.
Sound and picture interference	◆ Try to identify the electrical appliance that is affecting the television, then move it further away. ◆ Plug your television into a different mains socket.
Blurred or snowy picture, distorted sound	◆ Check the direction, location and connections of your aerial. This interference is often occurs to the use of an indoor aerial.
Remote control malfunctions	◆ Replace the remote control batteries. ◆ Clean the upper edge of the remote control (transmission window). ◆ Check the battery terminals.

Troubleshooting: Before Contacting Service Personnel (continued)

ENG

No operations can be performed with remote.	◆ Check the batteries in the remote. May need replacing. ◆ Operate the remote control at a distance of no more than 20 feet. ◆ Remove batteries and hold down one or more buttons for several minutes to drain the microprocessor inside the remote to reset it. Reinstall batteries and try remote again.
Disc does not play.	◆ Ensure that the disc is installed with the label side facing up. ◆ Check the region number of the DVD.
5.1 channel sound is not being reproduced.	◆ 5.1 channel sound is reproduced only when the following conditions are met. : 1) Check whether the proper amplifier is connected. 2) The disc is recorded with 5.1 channel sound. - Check whether the disc being played has the “Dolby 5.1 ch” mark on the outside. - Check if your audio system is connected and working properly. - In the **Audio Setup** menu, is the **Digital Output** set to **Bitstream**?
The ⊘ icon appears on screen.	◆ The features or action cannot be completed at this time because : 1) The DVD’s software restricts it. 2) The DVD’s software doesn’t support the feature (e.g., angles). 3) The feature is not available at the moment. 4) You’ve requested a title or chapter number or search time that is out of range.
Disc Menu doesn’t appear.	◆ Check if the disc has a Menu.
Playback mode differs from the Setup Menu selection.	◆ Some of the functions selected in the **Setup** Menu may not work properly if the disc is not encoded with the corresponding function.
The screen ratio can not be changed.	◆ The Screen Ratio is fixed on your DVDs.
No audio.	◆ Make sure you have selected the correct **Digital Output** in the **Audio Setup** menu.
Forgot password.	◆ If you have lost your password, enter the master password (1369), and then change password is displayed. ◆ Enter your new password. ◆ Enter your new password again to confirm. (refer to page 45)
If you experience other problems.	◆ Go to the contents and find the section of the instruction book that contains the explanations regarding the current problem, and follow the procedure once again. ◆ If the problem still cannot be solved, please contact your nearest authorized service center.

Wiring the Mains Power Supply Plug (UK Only)

ENG

IMPORTANT NOTICE

The mains lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and, if it requires replacing, a fuse approved to BSI1362 of the same rating must be used.
Never use the plug with the fuse cover omitted if the cover is detachable. If a replacement fuse cover is required, it must be of the same colour as the pin face of the plug. Replacement covers are available from your dealer.
If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance.
However, if there is no alternative to cut off the plug, remove the fuse and then safely dispose of the plug.
Do NOT connect the plug to a mains socket as there is a risk of shock hazard from the bared flexible cord.

IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

BLUE - NEUTRAL BROWN - LIVE

As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:
The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK.
The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RED.

WARNING: DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL, WHICH IS MARKED WITH THE LETTER E OR BY THE EARTH SYMBOL ⏚, OR COLOURED GREEN OR GREEN AND YELLOW.

C19A_ENG_03244A 1/20/04 11:54 AM Page 61

Memo

– AFTER SALES SERVICE

– Do not hesitate to contact your retailer or service agent if a change in the performance of your product indicates that a faulty condition may be present.

SAMSUNG ELECTRONICS

European Notice

Products with the CE marking comply with the EMC Directive (89/336/EEC), (92/31/EEC), (93/68/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Norms:

- **EN55013:1990**
  Radio Frequency Interference
- **EN55020:1994**
  Electromagnetic Immunity
- **EN61000-3-2:1995**
  Power Line Harmonics
- **EN61000-3-3:1995**
  Voltage Fluctuations
- **EN60065:1998**
  Product Safety

AA68-03244A-00